
Vertical retractable insect screen

LUXE VERTICAL


INSTALLATION INSTRUCTIONS

1




Fix the mounting brackets (d) to the wall on both sides. Snap the cassette into place with the handles facing inwards. FOR THE SMALL 36 mm CASSETTE: This cassette has no mounting brackets (d); screw it directly to the wall. FOR THE SPLIT VERTICAL SCREEN: Screw the central mounting brackets (d), between the cassettes, to the ceiling instead of the wall.

2




Fit the adjustable catches (e) into the bottom of the guide. The adjustable catch screws must face inwards.

3



Hold the guide diagonally, fit it onto the tabs projecting from the cassette and move it into position. Repeat with the other guide. Screw the adjustable catches to the floor or wall. Apply silicone around the screen perimeter to improve the seal and secure it in place.



Assembly overview